
CLAMP FOR INJECTION MOLDING

TOOLS FOR PROTECTION OF THE TIE-BAR

TIE BAR COVER





Bolt Size	Dimension	Block Height	Applicable Mold	Reference Tightening	Part Number	Unit Price
(8 Pieces)	Α	(mm)	Thickness (mm)	Torque (N•m)	(8 Pieces Set)	1~3 Set
M12×80	95			110	M-CE12-95	
M16×90	95	20×25	20,25,30,35	286	M-CE16-95	Quotation
W10 \20	130			286	M-CE16-130	











Quotation








■ Features

33

- Capable of height control in 4 levels. Height control can easily be done by just turning the block.
- Durable with long life service due to the clamp's fully forged body structure.

■ Application It is used for protecting the tie bar during mold removal and etc.



Applied	W	Quantity	Part Nur	Unit price	
tie bar dia. (ϕ)	(mm)	(pcs)	Туре	D	1~3 sets
38~48	26			38	
50~60	20			50	
63~73	29			63	
76~86		Yellow 16 Black 16	M-TBR	76	
89~99	32		IVI I DIK	89	Quotation
102~124				102	
127~149				127	كا
152~175	30			152	



Part Number
M — TBR — 38










■ How to use

Protects the tie bar when installing the mold.

CONVEYANCE ASSIST TOOL

DROP TRAY

SOFT CHUTE GUIDE SKIRT




W	0	н		Part Number		Unit price
VV	0		_	Туре	No.	1~3 pcs
300	150	200	610		1	
460	300	250	760	M-WSMS	2	Quotation
560	460	300	860		3	












■ Soft Chute Guide Skirt Mounting Description

1) Pass the shaft ② through the hole at the top of the soft chute guide skirt ① and attach the mounting stav ③ to the shaft ② .

2) To prevent the shaft ② from coming out, insert the set collar ④ and tighten the set screw on the side with the included hex wrench ⑥ .


3) Tap the mold as an M6 tap, pass the bolts 5 through the holes of the mounting stay 3 , and fix it to the mold.

4) Attach all bolts (§) . If it is firmly secured with the set collar (④) and does not come off when pulled or pushed by hand, mounting is complete.



D	А	1	ρ	н	h	Magnet	Part Number	Unit price	
	<u> </u>	_				Magnet	r art reamber	1~3 pcs	
435	390	765	566	170	160	No	M-WDTOOL		
433	390	700	300	170	170	170 100	Yes (4 pcs)	M-WDTOOL-MG	Quotation
610	560	970	756	200	180	No	M-WDTOOL2	Quotation	
010	300	310	730	200	100	Yes (4 pcs)	M-WDTOOL2-MG		














■ Drop Tray Mounting Description

- Attach the eyebolt 4 to the drop tray 1 and molding machine. For mounting, refer to the figure on the left. Drill holes into which the M6 bolts are inserted or provide M6 tapping on the molding machine.
- 2) Attach a chain ⑤ for hanging the drop tray ① from the molding machine.

The length of the chain (§) is about 1.8 meters. The links can be opened with a tool such as longnose pliers. Depending on the length of the chain (§), the inclination of the drop tray (1) can be changed. Install it at the length of your choice.

3) After attaching the chain \circ , hold down the drop tray \circ by hand. If it does not tilt or rattle, mounting is complete.

(When using magnets)


Attach the magnets to the molding machine instead of plate washers 6 , nuts 2 and eye bolts 4

Once done, mount in the same procedure as above. If it does not tilt or rattle, mounting is complete.

99

SHOOTER

MAGNET FIXED TYPE SCATTER GUARD



■ Product Shooter

- It is a tool for conveying molded products to be taken out by dropping to a container, etc.
- Install it in a space under the molding machine according to the location where the molded product is dropped.

• Use it for molded products that are smaller than the outlet size of the shooter.

■ Features

101

- Dust does not easily adhere thanks to the antistatic effect of polypropylene.
- As it is made of plastic, it can be wiped off if it gets dirty.
 If the dirt is severe, it can be wiped off with water and a neutral detergent.

Part Number	Unit price 1~9 pcs	
Fait Nullibei		
M-PSPM	Quotation	




Part Number













Set it under the molding machine.



① Red dashed lines in the figure above are valley folds.

② Insert the blue margin part shown above into the notch indicated by the blue solid line.



■ Magnet Fixed Type Scatter Guard

■ iviagi	Magnet Fixed Type Scatter Guard									
Α	d1	w	v	Part Number		Unit price				
A	uı	VV	v	Туре	D	1~3 pcs				
149	198	10	3		200					
280	295			Ī	300	ţi				
380	395	12	2	3	M-KSD	400	otai			
480	495	12	3	_	500	ž				
580	595				600					

■ Mag	■ Magnet (separate)								
Quantity	Material	Part Number	Unit price						
(pcs)	Material	Part Number	1~3 pcs						
8	Neodymium	M-KSDM8	Quotation						

Comes with two films on operation side and reverse operation side



Part Number
M - KSD - 200

M - KSDM8





Application


- · Attach four magnets to the molds on both the fixed side and movable side while the operation is stopped before molding.
- Attach the scatter guard to the hook of the magnet to complete installation.

■ Features

- · Firmly guards the molded parts from scattering.
- The transparent film enables confirmation of the interior.
- It is a type fixed with a magnet, making adjustment, relocation, opening and closing easy.

HEAT RETAINING COVER FOR HOPPER DRYER HOSE

■ Application Used to keep the hopper dryer hose warm.



L	Applicable	Part Nui	Unit price	
(mm)	Outer diameter of hose (ϕ)	Туре	D (\(\phi \)	1~3 pcs
	35~41		38	lon
600	47~53	M-DHI	50	otati
	60~66		63	8










- Depending on the work environment and ambient temperature, heat loss is about 14°C per 300 mm hopper dryer hose can be prevented.
- The applicable hose dimensions can be adjusted by surface fastener (width: 20 mm).

AIR TYPE VIBRATION PAD

PNEUMATIC VIBRATION PAD

Application Used to shake off powder inside the hopper.



Stem material	Color	Part Number	Unit price
Otem material	00101	T art Number	1~3 pcs
Carbon steel	Blue	M-SPA221	— Quotation)—
Stainless steel	White	M-SUSPA211	Quotation




Part Number M-SPA221 M-SUSPA211










Hopper cross section



How to use

- Drill a φ 22 hole on the hopper.
- 2. Remove the washers and nuts that are attached to the main unit, set so that the bolts of the vibration pad protrude from inside the hopper, then attach the washers and nuts. (Refer to the figure for the post mounting image.)
- 3. Install air piping in order to supply compressed air. The inner diameter of the vibration pad bolt is 1/4" NPT thread. (Since the shape is different from 1/4" PT, we recommend using an NPT → PT conversion plug.) Connect the air piping using a plug, coupler, hose joint, etc.
- 4. Supply air pressure of 0.2 MPa. Since it constantly vibrates and is pressurized while air is being supplied, powder will not enter the vibration pad.


Even when the air supply is stopped and the vibration stops, the vibration pad and hopper will be in close contact with each other, so there is no ingress of powder.

108 107

PELLET TANK

AIR HOPPER LOADER / PLATEN HOSE CLIP

AIR HOPPER LOADER / PLATEN HOSE CLIP



W	W ₁		P	н	Load weight	Product weight	Part Number	Unit price
**	VV1	_			(kg)	(kg)	Fait Nullibei	1~3 pcs
518	285	630	285	760	36	18	M-RB75LX	Quotation
613	380	735	380	970	71	35	M-RB150LX	- Guotation





Part Number M-RB75LX







■ Features

- It is space-saving as it can be stacked. (Up to 3 levels with empty tank)
- · Casters have locking function.
- · Since the air hopper loader can be inserted fully, it allows extraction with no material residue.


■ Function Description

[Cover for port]





• It is a cover with zipper. When a pick up wand is not used, impurities such as dust will not enter if the zipper is closed.

[Lid storage pocket]



· It is possible to store the lid of the tank.





Unit price **Part Number** 1 pc M-HOPVAC95308 Quotation

■ Connection Targets

Air amplifier: Material storage such as material tanks

(Air amplifier placed at the bottom of the material tank)

Aluminum U-shaped tube: Hopper for injection molding machine (Hook the U-shaped part on the hopper)










How to use


- 1 Connect air piping to the air supply port. Air pressure: 0.55 MPa (pressure gauge is not attached to this product).
- 2 Position the air amplifier downward, set it in the material tank, and hook the aluminum U-shaped tube on the opposite side to the hopper.
- 3 Make sure that the material is in the material tank and open the stopper of the ball valve next to the air supply port.
- 4 Material transport will start, and the transporting speed can be adjusted by opening and closing the valve.

■ Application Extends the hose life by preventing wear and bending of the hose. There is a screw size that fits most platens.



Screw size	Applicable external diameter of hose	Quantity	Part Num	nber	Unit price
(M×P)	(ϕ)	(pcs)	Туре	No.	1~20 sets
12×1.75				12	
14×2.0	16~29	10	M-PHC1	14	[⊆]
16×2.0	16~29			16	
20×2.5				20	Quotatio
12×1.75				12	1 181
14×2.0	9.5~19		M-PHC2	14	
16×2.0	9.5~19		M-PHC2	16	
20×2.5				20	









115